



Patch Imaging Kit - Electric Vacuum Pump Set-up Guide




How to fit and operate the optional electric vacuum pump

- Make sure the push-in fitting is clean and clear of any contaminant.
- Hold the back edge of the push-in fitting and slowly insert the 8mm diameter hose into the fitting hole.
- Firmly push the hose in until it stops – about 10mm.



- Secure the other end of the hose onto the supplied barb fitting.
- Push barbed fitting onto the stem on the base unit of the Nalgene chamber.



- Unscrew the top of the chamber.
- Using tweezers place the patch onto the plate. Place the top chamber back onto the patch, and tighten the screw.
- Pour fluid into the top chamber (up to the 100ml mark).



- Screw on the top chamber lid on.
- Remove one of the bungs.
- Turn on the vacuum pump.
- After the end of test, remove the hose from the Nalgene chamber.



- To remove the hose from the push-in fitting pull back the blue ring and at the same time pull the hose out.



How to order

PATCH IMAGING KIT - PIK	
Product	Order example
PIK Patch Imaging Kit	PIK P01
Pump and Electric supply options	
P01 Hand pump only	
P02 Electric Vacuum Pump - UK supply	
P03 Electric Vacuum Pump - EU supply	
P04 Electric Vacuum Pump - US supply	
P05 Electric Vacuum Pump - AUS/CN supply	